





ASSEMBLY INSTRUCTION

YHT C210A(SA)



- (A)**  **HEX NUT**
M8 = 8 PCS.
- (B)**  **FLAT WASHER**
5/16 X 1.2 = 8 PCS.
- (C)**  **SPANNER**
12.8 = 1 PC.
- (D)**  **ALLEN KEY**
= 1 PC.
- (E)**  **ADJUST SCREW**
M6 X 16 = 4 PCS.
- (F)**  **PEN HEAD SCREW**
M4 X 38 = 8 PCS.
- (G)**  **JCBC BOLT**
M6 X 40 = 4 PCS.
- (H)**  **SPRING WASHER**
WS 5/16 = 8 PCS.

